

Module 1 Unit 1 PRINCIPLES OF LASERS

(As per Revised Curriculum SVU R-2023)

• Introduction

LASER stands for "Light Amplification by Stimulated Emission of Radiation". Laser is a directional, focused, monochromatic, coherent and bright source of light. The difference in the nature of laser light from ordinary light is contained in the name itself - the process of *stimulated or triggered emission*. Ordinary light, on the contrary, is a result of *spontaneous or natural emission*. Stimulated emission cannot occur at normal conditions. The first successful laser source was the Ruby laser developed by T. H. Maiman in 1960. Following table gives a comparison between laser and ordinary sources of light.

Difference between laser courses and ordinary sources of light

	Laser Sources	Ordinary Sources
1)	Laser light consists of almost a single value of wavelength. The spread in wavelength is less than an Angstrom.	Light from ordinary sources consists of wide wavelength range. The spread in wavelength can be a few Angstroms for monochromatic sources and thousands of Angstroms for polychromatic sources.
2)	Laser light waves are highly coherent i.e. they are in phase with each other. The coherence length is few metres to few kilometres.	Ordinary light consists of waves with no definite phase relation. The coherence length is few millimetres to centimetres for all ordinary sources including monochromatic.
3)	Laser light has small angular spread, about 10^6 times smaller than ordinary light.	Ordinary sources emit light, which is highly divergent i.e. it has high angular spread.
4)	Laser light is directional. It is emitted only in one direction – along the axis of the source.	Ordinary light is emitted in all directions.
5)	The laser beam is highly intense. Large power is concentrated in a small part.	Intensity of ordinary light decreases rapidly with distance as it spreads everywhere.
6)	Examples of laser sources: He-Ne laser, Ruby laser, Nd:YAG laser, CO ₂ laser, diode laser	Examples of ordinary sources: CFL, halogen lamp, Na-vapour lamp, incandescent bulb, LED

• Laser beam parameters

1. Beam Intensity: It is a measure of optical power output from a laser source per unit area. It is expressed in W/m². Diode lasers typically have optical power of few mW while some gas lasers and solid state lasers have power output up to several kilowatts. Intensity of any laser source is given by the expression:

 $I = rac{P}{A'}$ where, P is optical power and A is area of cross-sectional area of laser beam

- 2. Monochromaticity: It is a measure of linewidth of radiation emitted from a source of light.

 Ordinary sources have linewidth up to 10¹⁰ Hz while laser sources have typical linewidths of 100 Hz only.
- 3. Coherence: It is a measure of coherence length. Coherence length refers to time and distance up to which the light waves emitted from a laser source are either in phase or bear a fixed phase difference with each other. Ordinary light sources have coherence length from a few mm to few



cm while laser sources have coherence lengths from a few m to a few km. the coherence length is given by the expression:

 $l_{coh}=rac{\lambda^2}{\Delta\lambda}$, where, $\Delta\lambda$ is the spread in wavelengths of the radiation emitted by a laser source and λ is the central wavelength.


- **4. Directionality:** It is the property of a laser source. Ordinary light is emitted in all directions. Laser light is emitted only along the axis of the laser source in the form of a cylindrical cavity.
- **5. Divergence**: It is a measure of angular spread of the laser beam as it travels away from a laser source. It is given by the expression:

 $\Phi=rac{d_1-d_2}{Z_1-Z_2}$, where Z_1 and Z_2 are axial/perpendicular distance of detector from laser source while d_1 and d_2 are diameters of laser beam at distance Z_1 , Z_2 respectively.

Inteaction of radiation with matter

Behind the emission of radiation in any form including light, there are three processes which involve interaction of radiation with matter. Radiation consists of photons and matter consists of atoms and molecules. Further, the most active constituents of any atom are electrons (at moderate energies upto a few evectron-volts). Obviously, interaction of radiation with matter means interaction of photons with atoms and molecules. The interaction can be as simple as light absorbed by a material or light emitted from a material. There are three processes, which coexist at all temperatures whenever there is an interaction between radiation and matter. Their proportion may change depending upon the material and its temperature. They are *Absorption, spontaneous and stimulated emission*.

Absorption



Consider an atom residing in the lower energy state E_1 and a radiation of certain energy is incident. The atom may absorb* the incident energy (if sufficient) and jump to the next energy state E_2 . This process is called as *induced or stimulated absorption* because we have to externally supply energy. The atoms will not automatically jump into the excited states. It means there is no spontaneous absorption as such.

(*Note that when we say an atom is excited, at all moderate energies upto a few electron volts, these are actually the orbital electrons, which exchage the energies and there are electron transitions. It is just symbolic to call transition of an electron to excited state as excitation of the atom)

Corresponding to each transition from E_1 to E_2 , one photon of energy $hv = E_2 - E_1$ disappears and the atom is excited. The number of atoms excited is by absorption process is given by,

$$\frac{dN}{dt}\Big|_{ab} = B_{12}N_1Q$$
Where,




B₁₂: probability of absorption process

N₁: number of atoms in lower energy level E₁

Q: energy density of incident radiation (given in J-s/m³)

The number of absorption events taking place at any instant is proportional to number of atoms present in the lower energy states. Since atoms tend to stay in the lowest possible energy states, most of the photons are absorbed as radiation penetrates the matter i.e. it is attenuated.

Spontaneous emission



An atom raised to its excited state does not stay there for long time because the excited state is inherently unstable. Excited atoms rapidly de-excite due to the natural tendency of atoms to seek for the lowest energy state. This type of process in which, atom on its own releases a photon is called as *natural or spontaneous emission*.

Corresponding to each transition E_2 to E_1 , one photon of energy $h\nu = E_2 - E_1$ appears. The number of atoms de-excited by spontaneous emission is,

$$\left. \frac{\mathrm{dN}}{\mathrm{dt}} \right|_{\mathrm{sp}} = \mathrm{A}_{21} \mathrm{N}_2$$

Where.

A₂₁: probability of spontaneous emission process


N₂: number of atoms in higher energy level E₂

The number of spontaneous emission events taking place at any instant is proportional to number of atoms present in the higher energy state. The process of spontaneous emission is completely probabilistic.

There is no control over spontaneously emitted radiation as it invloves transitions from varied energy levels with all possible directions and random phase factors. Therefore spontaneously emitted light is incoherent, divergent, diffused and undirected. It may or may not be monochromatic. Light from ordinary sources (e.g. bulb, tube light, LED, Na — light, candle, burner etc) is a result of spontaneous emission.

Stimulated emission

This type of process also exists along with the above two processes but at room temperature, spontaneous emission dominates over stimulated emission and the latter is generally negligible.





The idea behind stimulated emission is that the probabilities of absorption and emission in the presence of an external trigger like photons are equal. This was first shown statistically by Einstein. A photon of energy $hv = E_2 - E_1$ or greater can induce the excited atom (via momentum transfer) to de-excite to release energy in the form of another photon. The released photon is identical to the incident photon in every respect. This is called *induced or stimulated emission*.

Corresponding to every induced transition E_2 to E_1 due to a single photon, two identical photons of energy $hv = E_2 - E_1$ appear. The number of atoms de-excited by stimulated emission is,

$$\left. \frac{dN}{dt} \right|_{st} = B_{21} N_2 Q$$

Where,

B₂₁: probability of stimulated emission process

N₂: number of atoms in higher energy level E₂

Q: energy density of incident radiation

The number of stimulated emission events taking place at any instant is primarily proportional to number of atoms in the higher energy state.

Advantages of stimulated emission

The process of stimulated emission has following advantages over spontaneous emission:

- 1) The process is controllable from outside. We can control the intensity and energy density of inducing radiation.
- 2) The induced radiation is identical to the incident radiation in every respect: energy, frequency or wavelength, phase and direction of propagation.
- 3) By selecting proper active medium and resonance conditions, multiplication of photons is achieved. This leads to oscillations of radiation within a specially prepared region called as optical resonance cavity.

As a result, we get a highly monochromatic, coherent, directional, focused and intense. Thus, to obtain laser light means to obtain light amplification by stimulated emission of radiation at a desired wavelength.

Laser-Physics Terms and Concepts

When studying lasers, we come across to a number of important terms and concepts. Some of them are listed below to get a brief idea about principles of lasers.

1. Population

The number of *active* atoms occupying a particular energy state is called population of that energy state. Active atoms mean atoms, which are likely to be excited by incident radiation or atoms, which are already excited by absorbing photon/s and are about to de-excite. Thus, N_1 and N_2 is population of state E_1 and E_2 respectively. According to Boltzmann's statistics, the populations , N_1 and N_2 are given by

 $N_1 = g_1 e^{-E_1/kT}$ and $N_2 = g_2 e^{-E_2/kT}$ where, g_1 and g_2 are called "degeneracy" of levels E_1 and E_2 respectively. An energy level is said to be degenerate if the same energy level corresponds to different states (quantum states) of a system.

$$\therefore \frac{N_1}{N_2} = \frac{g_1}{g_2} e^{(E_2 - E_1)/kT}$$

Let both the energy levels E_1 and E_2 be non-degenerate and are singly occupied (only one quantum state corresponding to one energy level) so that $g_1 = g_2$ and

$$\frac{N_1}{N_2} = e^{(E_2 - E_1)/kT} --- (1)$$

At equilibrium, since $E_2 > E_1$, $N_1 >> N_2$ that is, the lower state E_1 is said to be *populated* as compared to the excited state E_2 which seems obvious.



2. Equilibrium conditions and Einstein's coefficients

At equilibrium (dynamic equilibrium, where energy exhange takes place), the number of upward transitions is equal to the number of downward transition so that the ratio N_1/N_2 remains constant. This gives

$$\left. \frac{dN}{dt} \right|_{ab} = \left. \frac{dN}{dt} \right|_{sp} + \left. \frac{dN}{dt} \right|_{st}$$

$$B_{12}N_1Q = A_{21}N_2 + B_{21}N_2Q$$

According to Einstein's statistical theory, the probabilities of stimulated events i.e. absorption and emission are the same i.e. is $B_{12} = B_{21}$. Therefore we get $\frac{N_1}{N_2} = 1 + \frac{A_{21}}{B_{22}}$.

Using (1) above, we can write:

$$Q = \frac{A_{21}}{B_{21}} \left(\frac{1}{e^{(E_2 - E_1)/kT} - 1} \right)$$

Let $E_2 - E_1$ corresponds to radiation of energy E = hv, where v is frequency of radiation according to Planck's formula.

$$\therefore Q = \frac{A_{21}}{B_{21}} \left(\frac{1}{e^{h\nu/kT} - 1} \right)$$

Comparing this equation with the Blackbody radiation formula according to Planck's theory:

$$Q = \frac{8\pi h \nu^3}{c^3} \left(\frac{1}{e^{h\nu/kT} - 1} \right) - - - (2)$$

we get
$$\frac{A_{21}}{B_{21}} = \frac{8\pi h \nu^3}{c^3} --- (3)$$

It indicates that the ratio of probabilities of spontaneous to stimulated emission goes as cube of frequency of radfiation emitted. This indicates that achieving laser emission i.e. stimulated emission becomes more and more difficult at higher frequencies or shorter wavelengths.

Above ratio is also called ratio of Eintein's A dn B coefficients.

Further, let us find the ratio of rates of spontaneous and stimulated emission:

$$R = \frac{\frac{dN}{dt}|_{sp}}{\frac{dN}{dt}|_{st}} = \frac{A_{21}N_2}{B_{21}N_2Q} = \frac{A_{21}}{B_{21}Q}$$

Using (2) and (3) above, we get

$$R = e^{h\nu/kT} - 1$$
 --- (4)

Equation (4) gives the ratio of rates of spontaneous and stimulated emission processes. It indicates that for a given frequency of radiation, the ratio varies exponentially with temperature.

Laser emission is a non-equilibrium process

At room temperatures and at thermal equilibrium, absorption and spontaneous emission processes nearly balance each other. At equilibrium, $N_1 \gg N_2$ and also, $A_{21} \gg B_{21}$. RHS of both terms are less that unity and the stimulated emission is negligible with other two processes. Therefore, we do not observe laser light in normal conditions and the light due to all ordinary sources is a result of spontaneous emission processes.



For stimulated emission, Q must be made large enough so that product on RHS of first term becomes greater than unity. Further, we have to make $N_2 > N_1$. Since this cannot happen naturally, we have to supply energy to the atoms and maintain them in higher energy levels. To achieve stimulated emission we have to make $N_2 > N_1$. But this is reserve condition of what is observed at equilibrium condition. Since we have to disturb the equilibrium condition, lasers are often called as *non-equilibrium processes*.


3. Population inversion

There must be more atoms in the higher energy level E_2 than in the lower energy level E_1 in order to achieve stimulated emission exclusively. This is a non-equilibrium process as noted above in which the higher energy state is pore populated than the lower energy state. When this situation is achieved, the population between the energy levels E_1 and E_2 is said to be inverted and the medium or region in which this is achieved is said to be transferred in the state of population inversion.


4. Pumping

For maintaining the state of population inversion, the atoms have to be continuously raised to excited states. It requires energy to be supplied to the system from outside. The process of supplying energy to the system with an objective of keeping it into the state of population inversion is called as pumping. Various methods used for pumping are:

A) **Optical pumping:** A source of light (photons) is used to supply energy. For example, in Ruby laser, the Ruby crystal is surrounded by Xenon flash lamp. The material absorbs the incident radiation and a number of Cr³⁺ ions are excited to higher states. Stimulated emission results if necessary population inversion is achieved properly.




B) Electrical pumping: An electric field is set up by a pair of oppositely charged electrodes. For example, in He-Ne laser, the molecules of helium are ionized and accelerated by the electric field. They gain kinetic energy in this process making many molecules to get transferred into the excited states. Stimulated emission results when population inversion is achieved.



C) Direct conversion: Electrical current itself achieves pumping. This is achieved in diode lasers. The energy levels used are conduction band and valence band. The forward bias enhances diffusion currents of holes and electrons to flow into either sides getting many electrons in




the conduction band and holes in the valence band. The population inversion is established between these energy bands.



5. Pumping schemes

Generally, three or more energy levels are involved in the event of laser output (except for diode lasers). The systems in which three energy levels are involved are said to have *three-level pumping* scheme e.g. Ruby laser and those using four energy levels are said to have *four-level pumping* scheme e.g. He-Ne laser and Nd:YAG laser. The energy levels, which are actually involved in laser transitions, are called as *upper and lower lasing levels* and the transition between these states is called as *laser transition* (indicated by green waves).



- A) Three level pumping: In three-level pumping, the lower level is normally, the ground state energy level (black coloured). The atoms are first raised from the ground state to an excited state E₃ (red coloured). These atoms normally de-excite to an intermediate energy state E₂ (blue coloured) by some non-radiative process like emission of heat energy. E₂ being a metastable state, the atoms, they have lasing transition from there to the ground state E₁ (green coloured). The atoms have to be constantly raised from the ground state to an excited state. It is very difficult to alter the population of the ground state since it is the most stable energy level. High pumping power is required to achieve population inversion.
- B) Four level pumping: In four-level pumping, lower as well as upper energy levels are some intermediate excited energy states. Atoms are first pumped to an excited state E₄ (red coloured). From there, they quickly return to level E₃ (blue coloured) by some non-radiative process like emission of heat. E₃ being a metastable state, the atoms have a lasing transition to state E₂ (green coloured). From E₂ again they de-excite to ground state by transferring energy during non-radiative process like collisions etc. It is easier to achieve population inversion between two excited states rather than pumping atoms continuously from the ground state.



Population inversion is achieved faster. Further, Lesser pumping power is required to keep lasing transitions going once the atoms are raised to higher energy levels from the ground state. Therefore four-level pumping schemes are efficient that three-level schemes.

C) Two level pumping: This word is quite misleading because the levels are not singular energy states but they are rather energy bands. Such type of pumping is achieved in diode laser. The electrons are transferred from the valence band to the conduction band and they come back to valence band by giving laser radiation (green coloured). Some of the input energy is of course, lost but the diode lasers can give maximum output efficiency even better that 70% at times.

6. Meta stable state

Excited atoms have natural tendency to rapidly de-excite to their ground states. This process usually occurs within 10⁻⁸ seconds. However, there are certain energy states in which excited atoms can reside for as long as 10⁻³ seconds. This interval is long compared to normal de-excitation times of atoms. Therefore these states are called *metastable states*.


For stimulated emission to occur, the atoms are required to occupy the upper energy level until the triggering radiation is incident. The metastable state allows accumulation of atoms in a higher energy level and we can practically realise the state of population inversion. Meta stable states are extremely important because they assist in maintaining the condition for population inversion (viz. $N_2 > N_1$). Otherwise population of the excited states would rapidly decrease and there would be no laser transitions. In fact, the invention of lasers could not have taken place if elements offering metastable states were not discovered. For example the 2s and 3s states of Ne^+ ions having energies 18.7 eV and 20.66 eV, in He-Ne laser, 4p energy state of Ar^+ ions in Argon gas laser or 1.4 eV energy level of Cr^{3+} ions in Ruby laser are actually metastable states.

7. Active system or active medium


The region in which the state of population inversion is achieved is called as the *active medium* or active system. The actual laser light is emitted from this region. The system can be a solid, liquid or gas. Further, the whole system may not take part in population inversion; only a fraction of it is responsible. For example, in semiconductor diode laser, it is the depletion region which goes in the state of population inversion and not the entire diode. In Ruby laser, the lattice sites occupied by Cr^{3+} ions act as active centres and the Al_2O_3 crystal (Ruby) just acts as host and heat sink.

8. Resonant cavity/Optical resonator

Light emitted in the active medium of a laser source initially consists of mostly spontaneously emitted photons. These photons do trigger stimulated emission but since the inducing photons were randomly directed, the stimulated photons are also scattered in all directions. Moreover, they may be incoherent and have random phase. Thus, there is a requirement of tuning all or most of the stimulated radiation. This is achieved by means of a resonant cavity.



9. Threshold condition for lasing:



Consider a resonance cavity as above with length L. R₁ and R₂ are the reflectivity of two mirrors. Let γ be the overall gain coefficient and α be the overall loss coefficient of the active medium (resonance cavity). The pumping radiation (stimulus) triggered at any arbitrary point A within the active medium will lead to a stimulated emission. For convenience, let the emitted radiaition is directed towards mirror 1. It gets reflected and traverses through the active medium, gets reflected from mirror 2 and comes back at point A, where it started thus completing a round trip.

let the initial intensity of the pumping radiation be Io. Intensity of radiation after traversing distance x from the active medium is given by

$$I(x) = I_0 e^{(\gamma - \alpha)x}$$

On reflection at mirror 1, intensity of radiation becomes $I(x) = R_1 I_0 e^{(\gamma - \alpha)x}$ and after reflection at mirror 2 the intensity gets further modified to $I(x) = R_1 R_2 I_0 e^{(\gamma - \alpha)x}$. Thus, after one round trip, the intensity will become

$$I = I(x = 2L) = R_1 R_2 I_0 e^{(\gamma - \alpha)2L}$$

 $\frac{1}{I_0} < 1 \Rightarrow$ net attenuation, laser radiation dies out. $\frac{1}{I_0} > 1 \Rightarrow$ net amplification $\frac{1}{I_0} = 1 \Rightarrow$ custon

$$\frac{\ddot{l}}{l_0} > 1 \Rightarrow$$
 net amplification

$$\frac{1}{I_0} = 1 \Rightarrow$$
 sustained oscillations

The last two conditions together correspond to light amplification, which is an essential step for laser emission. In particular, the last condition tells about the condition on overall gain factor for onset of stimulated emission dominance over spontaneous emission.

By taking
$$\frac{I}{I_0}=1$$
 , we get $R_1R_2e^{(\gamma-\alpha)2L}=1$ or $e^{(\gamma-\alpha)2L}=\frac{1}{R_1R_2}$

Taking log on both sides,

$$(\gamma - \alpha)2L = \ln\left(\frac{1}{R_1R_2}\right)$$
. Rearranging, we get

$$\gamma = \alpha + \frac{1}{2L} \ln \left(\frac{1}{R_1 R_2} \right)^2 \quad --- (5)$$

Equation (5) above is called as "threshold condition fo lasing action".

END OF DOCUMENT
